



GPU Control Box Assembly

Model No. RMBEM78690GPUCBA12

Diagram:







R.M.B Enterprises

A Name to Trust

RMBEM78690GPUCCA12





R.M.B Enterprises

A Name to Trust

RMBEM78690GPUCBA12

Part list:

Sr. No.	Description	Part Number	Qty.
1	Engine Temp Meter	RMBEM78690GPUCBA12-001	1
2	DC Ampere Meter	RMBEM78690GPUCBA12-002	1
3	Time Meter	RMBEM78690GPUCBA12-003	1
4	Engine Fuel Gauge	RMBEM78690GPUCBA12-004	1
5	Engine Oil Pressure Meter	RMBEM78690GPUCBA12-005	1
6	AC Frequency Meter	RMBEM78690GPUCBA12-006	1
7	AC Ampere Meter	RMBEM78690GPUCBA12-007	1
8	AC Voltage Meter	RMBEM78690GPUCBA12-008	1
9	EF Bypass Indicator Light	RMBEM78690GPUCBA12-009	1
10	Lamp ON/OFF Button	RMBEM78690GPUCBA12-010	1
11	Engine Start Button	RMBEM78690GPUCBA12-011	1
12	Output ON/OFF Button	RMBEM78690GPUCBA12-012	1
13	Military Button	RMBEM78690GPUCBA12-013	1
14	Engine STOP Button	RMBEM78690GPUCBA12-014	1
15	Test/Reset Button	RMBEM78690GPUCBA12-015	1
16	Voltage Selector Switch	RMBEM78690GPUCBA12-016	1
17	Panel Indicator Lights	RMBEM78690GPUCBA12-017	9
18	Generator Set Control Board	RMBEM78690GPUCBA12-018	1
19	Memory & Time Delay Card	RMBEM78690GPUCBA12-019	1
20	Under/Over Frequency Card	RMBEM78690GPUCBA12-020	1
21	Under/Over Voltage Card	RMBEM78690GPUCBA12-021	1
22	AVR Card	RMBEM78690GPUCBA12-022	1
23	Panel Lights	RMBEM78690GPUCBA12-023	2
24	Terminal Base	RMBEM78690GPUCBA12-024	1
25	Timer Relay	RMBEM78690GPUCBA12-025	1
26	Harness Wire	RMBEM78690GPUCBA12-026	Misc.
27	Diagnostic Switch	RMBEM78690GPUCBA12-027	1
28	Output Test Switch	RMBEM78690GPUCBA12-028	1
29	Military Commercial Switch	RMBEM78690GPUCBA12-029	1
30	Contactors Button	RMBEM78690GPUCBA12-030	1
31	Marker Lights Button	RMBEM78690GPUCBA12-031	1
32	Control Button	RMBEM78690GPUCBA12-032	1
33	Engine Button	RMBEM78690GPUCBA12-033	1
34	Receptacle Power	RMBEM78690GPUCBA12-034	1
35	Receptacle optional	RMBEM78690GPUCBA12-035	1
36	Receptacle Engine	RMBEM78690GPUCBA12-036	1
37	Receptacle Power Module	RMBEM78690GPUCBA12-037	1